

INSTALLATION & USER MANUAL

CEILING FAN WITHOUT LIGHT



Item#40042-BK-NL

Customer Service: support@ceilingfanhelp.com


Fan Blades
Accessory Kit
Motor Assembly
Canopy Cover/
Yoke Cover
Remote Control & Receiver/
Decorative cover
Downrod 5"
Mounting Bracket/
Canopy


Downrod 10"

Table of Contents

Table of Contents.....3
Safety Information.....3
Dimension Reference.....4
Hardware Included.....4
Fan Parts Included.....4
Exploded View.....5
Installation Instructions.....6-11
Troubleshooting Guide.....12
Balancing Kit.....13

Safety Information

READ AND SAVE THESE INSTRUCTIONS.

1. To reduce the risk of electric shock, ensure the power is turned off at the circuit breaker or fuse box before installation.

2. All wiring must be in accordance with the National Electrical Code “ANSI/NFPA 70” and local electrical codes. Electrical installation should be performed by a qualified licensed electrician.

3. Make sure the outlet box and support structure are securely mounted and rated to safely support a fan weighing up to 35 lbs (15.9 kg); this fan must be installed on a UL-listed outlet box clearly marked “Acceptable for Fan Support of 35 lbs (15.9 kg) or less.” If you are unsure about safety or compatibility, please consult a qualified electrician.

4. Do not place objects in the path of the blades.

5. To clean the fixture,turn off the power, wait for it to cool, and wipe the fixture with a clean, soft cloth.

6. After making electrical connections, spliced conductors should be turned upward and carefully pushed into the outlet box. The wires should be spread apart with the grounded conductor and the equipment-grounding conductor on one side of the outlet box and ungrounded conductor on the other side of the outlet box.

7. All set screws must be checked and retightened where necessary before installation.

WARNING: To reduce the risk of electric shock or fire, do not use this fan with any solid-state fan speed control device. Such use will permanently damage its electronic circuitry.

WARNING: To reduce the risk of personal injury, do not bend the blade brackets during installation, blade balancing, or fan cleaning.

WARNING: To reduce the risk of fire, electric shock or personal injury, mount to outlet box marked “acceptable for fan support of 35 lbs. (15.9 Kg) or less” and use screws provided with the outlet box.

WARNING: To avoid possible electrical shock, turn the electricity off at the main fuse box before wiring.

WARNING: To reduce the risk of electrical shock, this fan should not be installed with an isolating wall control or switch, as it may cause incompatibility issues.


CAUTION: To reduce the risk of personal injury, use only the screws provided with the outlet box.

CAUTION: Please use carefully when working around or cleaning the fan to avoid injury or damage to the fan.


CAUTION: The fan must be mounted with a minimum of 7 ft (2.1 m) clearance from the trailing edge of the blades to the floor.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

Dimension Reference




Hardware Included




Hardware Package	Quantity
S1. J-box Screw	2
S2. Self-tapping Screw	4
S3. Washer	4
S4. Spring Washer	4
S5. Wire Nut	3
S6. Expansion Screw	2
S7. Fan Blade Screw	2
S8. Paper Gasket	26
S9. Blade Bracket Screw	1
S10. Balance Kit	1+2

Fan Parts Included



Item Name	Quantity
1.Remote Control & Receiver	1
2.Mounting Bracket	1
3.Downrod (5" + 10")	2
4.Canopy	1
5.Canopy Cover	1
6.Yoke Cover	1
7.Motor Assembly	1
8.Decorative cover	1
9.Fan Blades	8

Exploded View



Installation Instructions

Step1 Installing the hanger bracket

WARNING: To reduce the risk of fire, electric shock, or personal Injury, mount to UL/CSA listed outlet box marked acceptable for fan support and use mounting screws provided with the outlet box.

- Locate ceiling joist where the fan is to be mounted, being sure location agrees with the requirements in the minimum clearance section of this guide.Wood joists must be sound and of adequate size to support 70 pounds.(Fig.1a)
- Choose expansion anchors or wooden screws for installation based on the material of the ceiling. If the weight of the fan assembly exceeds 15KG, at least 4 screws need to be installed to fix the hanger durina installation.(Fig.1b)

Fig.1a





Fig.1b



- If the fan is being installed on a concrete ceiling without an outlet box, use two expansion screws.
- Use an impact drill to drill two Ø 8 mm (5/16") holes. Note that the distance between the two holes should be approximately 100 mm (3.94").
- Insert the expansion anchors fully into the holes, then remove the washers and nuts.
- Place the mounting bracket onto the expansion anchors, reinstall the washers, and tighten the nuts with a wrench. (See Fig.1c and Fig.1d)




Fig.1c





Fig.1d

Step2 Attach the fan blades to the motor assembly.

- As shown in the diagram, secure the component depicted in Fig.2a to the motor using screws.Ensure the screws are tightened properly.(Fig.2a)

Fig.2a




Repeat x8

Step3 Install decorative cover

- Rotate the mounting base of the decorative cover clockwise into the lamp holder until it clicks securely into place. (Fig. 3)
- Remove the light cover from its packaging and fit it onto the lamp holder as illustrated.

Fig.3a



Step4 Hanging the fan

- Take out fan downrod. Remove the cotter pin and the downrod pin from the downrod. (Fig.4a)
- Place the downrod inside the canopy, canopy cover, and yoke cover. (Fig.4b)
- Carefully feed the electrical lead wires and safety cable from the fan through the downrod. Insert the downrod pins into the mounting collar and downrod. Clip the cotter pin through the small hole at the end of the downrod pins to secure the downrod in place. (See Fig. 4c)
- Secure downrod in position by tightening jam screws.(Fig.4d)
- Slide the yoke cover down, and it will flush with the motor housing.

CAUTION: To ensure wobble-free operation and to avoid damage to the fan, the downrod and the jam screw must be completely tightened.

Fig.4a




Fig.4b




Fig.4c




Fig.4d






Fig.4e



Step 5 Installing the receiver

- Place the receiver in the mounting bracket.



Step6 Wiring the Fan

- Connect the wires to the corresponding terminals as shown in the wiring diagram.






Fig.6a

Step 7: Installing the Canopy and Completing the Installation

- Slide the canopy up and secure it to the mounting bracket with the provided screws. Ensure all screws are tightened securely. Attach the small cover to the top.

Fig.7a






CONGRATULATIONS!
YOU HAVE COMPLETED THE INSTALLATION

Installation Instructions

Remote Control Instructions

Open the battery cover on the handheld remote and install two AAA batteries (1.5V) that are not included.

1.Fan All Off
2.Speed Control
3.Natural Wind Mode
4.Timer 1 Hour
5.Reverse Mode
6.Timer 2 Hour
7.Timer 4 Hour
8.Timer 8 Hour



Pairing Instructions:

Turn on the power switch and press the "power" button within 5 seconds. The receiver will emit two 'beep' sounds if the pairing code is successful. If not successful, turn off the power for one minute and repeat the process.

Troubleshooting:

When the remote control cannot control the receiver, please check the battery contact, ensuring the positive and negative terminals are correct, and that the battery is fully charged.

When the remote control cannot control the receiver, please check if there are any similar remote-controlled products nearby. If there are, check whether they work, as remote-controlled products with the same frequency may interfere with each other.

Please remove the battery from the remote control when it is not in use for an extended period of time.

Troubleshooting Guide

If you have difficulty operating your new ceiling fan it may be the result of incorrect assembly,installation,or wiring.In some cases these installation errors may be mistaken for defects.If you experience any faults please check this troubleshooting guide.

	Problem	Suggested Remedy
1	If fan does not start.	□ Check the main and branch circuit fuses or breakers. □ Check the line wire connections to the fan and switch wire connections in the switch housing. □ Check the battery in the remote control. □ Ensure you are in the normal range of 10-20 feet.
2	If fan sounds noisy.	□ Ensure all motor housing screws are snug. □ Ensure the screws that attach the fan blade bracket to the motor hub are tight. □ Ensure the wire nut connections are not rattling against each other or the interior wall of the switch housing. □ Allow a 24-hour “breaking in” period. Most noises associated with a new fan disappear during this time. □ If you are using the Ceiling Fan light kit, ensure the screws securing the glassware are tight. Check that the light bulbs are also secure. □ Ensure the canopy is a short distance from the ceiling. It should not touch the ceiling. □ Ensure your outlet box is secure and rubber isolator pads were used between the mounting plate and outlet box.
3	If fan wobbles.	□ Check that all blades are screwed firmly into blade holders. □ Check that all blade holders are tightened securely to motor. □ Make sure that canopy and mounting bracket are tightened securely to ceiling junction box and junction box is mounted firmly to ceiling joist. □ Most fan wobble problems are caused when blade levels are unequal.Check this level by selecting a point on the ceiling above the tip of one of the blades keeping measure within 1/8 in.Rotate the fan until the next blade is positioned for measurement.Repeat for each blade.If all blade levels are not equal you can adjust blade levels by the following procedure.To adjust a blade tip down insert a washer(not supplied)between the blade and blade holder at the screw closest to the motor.To adjust a blade tip up insert washer(not supplied)between the blade and blade holder at the two screws farthest from the motor. □ If blade wobble is still noticeable interchanging two adjacent (side by side)blades can redistribute the weight and possibly result in smoother operation.
4	If light does not work.	□ Check blue wire from fan to make sure it is connected to hot wire from the house. □ Check for loose or disconnected wires in fan switch housing. □ Check for loose or disconnected wires in light kit. □ Check for faulty light bulbs.CAUTION:Make sure main power is turned off before entering switch housing. □ If the fan light shuts off shortly after being switched on it may be due to excessive current demand.Turn off power to the fan and replace the light bulbs with lower wattage bulbs.Turn on power to the fan using the pull chain,wall switch,or remote control (whichever is installed on the particular fan).

Balancing Kit

Use the balancing kit only if excessive fan wobble persists after completing all the steps under “Attaching the Fan Blades’’ in your Owner’s Manual.

1. Turn on the fan and set it to the speed where the wobble is most noticeable.
2. Turn off the fan and allow it to come to a complete stop. Select one blade and place the balancing clip halfway between the blade holder and the tip, on the trailing edge.
3. Turn the fan back on and observe whether the wobble has increased or decreased. Repeat the test on each blade, noting which one shows the most improvement.
4. Move the clip back to the blade that showed the greatest improvement. Adjust the clip’s position slightly inward and outward along the blade to find the optimal location.
5. Remove the clip and attach a balancing weight to the top of the blade, near the clip position, along the centerline.
6. If the wobble persists, you may further improve the balance by using the clip and additional weights.

